



CONNECTVIEW™ WEB APP

OVERVIEW

What Is The ConnectViewTM Web App?

CTC's complimentary ConnectViewTM Web App comes preloaded on the ConnectBridgeTM Gateway and offers basic vibration tools and device management functionality, including:

- Configure WS200 and WS300 Series Sensor (Please note, WS100 is factory configurable only)
- Nickname sensors
 - Set critical and early alert values which can be viewed through the ConnectViewTM Web App
- Create machine groups
- View battery life
- Request readings on demand (WS200 & WS300 only)
- View basic vibration data:
 - WS100 View overall vibration amplitude in RMS, Peak, and Peak to Peak WS200 & WS300 View FFT and Time Waveform data



Logging In


You can access the ConnectViewTM Web App on any device, using any web browser.





Logging In


First time users – use this link to create an account when logging in for the fist time




Returning users – enter your email and password, then click Log In



Dashboard








Alerts

Use the check boxes to select what alerts to display



Use the buttons to view or acknowledge the alert




Trends

Use the dropdown to choose type of vibration value you'd like displayed










Click on any trend to view the sensor's page



Favorites


Click on any of your favorite devices to view the device's page





Devices - Sensors

View all your sensors at glance



Dynamic sensors will be labeled connected or disconnected

Click on any sensor to view its page




WS100 Sensor Page

View basic sensor info

Set as favorite, edit name, or remove sensor

Set Critical Alert or Early
Alert Settings by
clicking on the three
dots in the corner




The other specs shown are not user-configurable for WS100



WS100 Sensor Page

period







View basic sensor info

Set as favorite, edit name, disconnect, or remove sensor


User-configurable specifications – click on the three dots in the corner to configure












data for all three axis per reading.

your selected reading. Note, WS300 triaxial sensors will show

Once you've selected a date and timeframe and clicked Search, a dropdown menu will appear. You can select from any reading during your specified timeframe.






The FFT chart for your selected reading will be displayed. You can click and drag on the chart to zoom to a specific frequency.


For WS300 triaxial sensors, you can toggle between axes to view FFT charts for each axis





Use the Export to CSV button to download your FFT






The Waveform chart for your selected reading will be displayed. You can click and drag on the chart to zoom to a specific frequency.

you can toggle between axes






Use the Export to CSV button to download your Waveform data.



Devices - Gateway



Click on any gateway to view its page




Gateway Page






Machine Groups





Machine Groups




To create a new machine, click the New Machine button, then enter a machine name, description, and location and click Save



Machine Groups

Click on a machine group on the left to view and manage it



Click the yellow + button to add a sensor to the machine group


Use the arrow button in the right corner to view sensor alert info

All the sensors assigned to the machine group will appear here



User Accounts

View all user accounts




Use these buttons to edit user permissions or remove users




User Accounts

Edit user info including name, alerts, and role





Settings





Connect with CTC

We look forward to hearing from you

