
JB930


Four-Position Plugs for Dual Input and Output Junction Boxes



JB930-1A








Four-Position Plug, Spring Cage, for use in DSB, JB, and SB Dual Input and Output Junction Boxes

JB931-1A








Four-Position Plug, Screw Terminal, for use in JB and SB Dual Input and Output

Junction Boxes

JB931-3A







Four-Position "T" Plug, Screw Terminal, for use in DSB Dual Input and Output Junction Boxes