

# CTC CONNECT



## ACCESS360 ConnectBridge™ Gateway Troubleshooting Guide

# TABLE OF CONTENTS

- Introduction ..... 3
- Troubleshooting ..... 4
- Maintenance..... 5
- Warranty and Refund Information ..... 5



## INTRODUCTION

The ACCESS360 functions as a network controller and **Bluetooth®** gateway that facilitates bi-directional data transfer with CTC Connect Wireless Sensors within range.

ACCESS360 can accept an unlimited number of sensor inputs with 20 concurrent Bluetooth® connections at one time.

Rated IP67, the ACCESS360 can withstand harsh environments including temperatures ranging from -4 °F to 158 °F (-20 °C to 70 °C). A cover featuring four self-tapping screws allows the box to be sealed from the elements. There is no need to remove the cover, except for if the SD card needs to be replaced. When the gateway is fully powered on, a green LED light will be visible through the clear lid.

## TROUBLESHOOTING

### Unable to load the Web App UI on a workstation

1. Cycle power to the gateway by disconnecting the Ethernet cable, waiting 10 seconds, and reconnecting it.
2. Obtain the gateway's IP address from your network administrator.
3. Open a browser on a network connected workstation and enter the gateway's IP address.

### Sensor is not connecting to the gateway

1. Cycle power to the sensor by disconnecting the battery, waiting 10 seconds, and reconnecting it.
2. From the Dashboard, click the Settings Button on the left.
3. Click on Gateway Bluetooth® Settings, then Bluetooth® Reset.
4. Click on Restart Gateway Settings, then Reboot.

### Access Point not powering on

1. Ensure the power sourcing equipment complies with PoE IEEE standards
2. Check the power-sourcing device is not set to a passive powering mode
3. Inspect cabling for correct wiring or breaks

### Performing a factory reset

1. Remove lid
2. Press and hold the button marked "ETH Boot"
3. Wait until the LEDs turn off and back on
4. Reinstall the lid

### Transfer Data to the New Gateway

1. Power off Gateway
2. Remove lids from both Gateways
3. Place the SD card from the old Gateway into the new Gateway
4. Reinstall the lid

## MAINTENANCE

Once the system has been installed, it requires minimal maintenance. Basic checks to ensure system integrity should be made periodically.

Visual inspection should include examinations for the following:

1. No visible electrical burns or smoke inside the enclosure.
2. No moisture or condensation is present inside the enclosure.

## WARRANTY AND REFUND

Please visit [www.ctconline.com](http://www.ctconline.com) to view a complete recapitulation of our warranty and refund policies.

## DISCLAIMER

The ACCESS360 contains software and firmware proprietary to CTC. Use of the ACCESS360 is, at all times, subject to the CTC's then current Software End User License Agreement available at [www.ctconline.com](http://www.ctconline.com). All data and information provided by, or collected from, you is subject to CTC's Privacy Policy available at [www.ctconline.com](http://www.ctconline.com).

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Connection Technology Center, Inc. (CTC) is under license. Other trademarks and trade names are those of their respective owners.

